

BACOBAN^{WB} DISINFECTION & CLEANING CONCENTRATE

WATER-BASED

Alcohol-Free | Use the mixing table

Residual antimicrobial effect for up to 10 days

Effective against Coronavirus

Composition:

100 g of solution containing: Benzalkonium chloride 26.0 g, sodium pyrithione 2.5 g, polycondensates, perfume substances, purified water, formaldehyde-free, phenol-free. Ingredients according to regulation (EC) No 648/2004: 15 % or over but less than 30 % cationic surfactants, disinfectants, perfumes (Linalool, Limone, Citral, Geraniol, Citronellol)

Residual antimicrobial effect for up to 10 days (tested according to ASTM E 2180).

Dermatologically tested (at 1 %): excellent skin tolerance

Important!

The residual antimicrobial effect of Bacoban WB is no excuse for not carrying out necessary disinfection measures in cases of visible and/or questionable contamination!

Use disinfectants safely. Always read the label and product information before use.

Safety instructions:

The product can be used without gloves, provided that infection and work protection allow it. Harmful if swallowed. Causes severe skin burns and eye damage. Very toxic to aquatic life. Keep out of reach of children. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Dispose of contents/container to special waste collection point. Contains Linalool. May produce an allergic reaction. Toxic by eye contact. Pyridin-2-thiol-1-oxid, sodium salt.

Use only with water and according to the mixing table. Do not use with other cleaners or disinfectants. Can be used on all surfaces. For possibly sensitive surfaces, we recommend testing for compatibility first on a less visible place. Store only in closed container, cool and dry. Container cannot be recycled until it is completely empty. Dispose of properly in accordance with local and official regulations.

Officially regulations: Once opened, use within 12 month. Do not use product after expiry date.

Biocide Reg.No: N-94432

The ready-to-use solution based on the mixing table does not have to be labelled with a danger symbol.

Distributed by:
aviationscouts GmbH
Wendenstraße 40
D-96215 Lichtenfels
+49 9571 947 907 0
www.aviationscouts.com

Danger



Efficacy and dosage	5 min	15 min	30 min	60 min	240 min
VAH list (Bactericidal and yeasticidal efficacy)					
Tested in accordance with VAH requirements 2015 (with mechanical action, dirty conditions)	1,00 %				
EN 14476 and Guideline DVV / RKI					
Virucidal activity against enveloped viruses (incl. Coronavirus, HIV, HBV, HCV, Influenza, Herpes, Ebola virus,...)	1,00 %				
EN 14476					
Adenovirus					2,00 %
Human papillomavirus (HPV)				1,00 %	
Norovirus			1,00 %		
Rotavirus	0,10 %				
Tested in accordance with EN guidelines					
EN 16615 (4-field-test)	1,00%				
EN 1040	0,25%				
EN 1275	0,25%				
EN 1276	0,75%	0,50%			
EN 1650	0,50%	0,25%			
EN 13624 (C. albicans)	1,00%				
EN 13624 (T. interdigitale)	1,00%				
EN 13697		0,5 %			
EN 13727	1,00%				
EN 14561	3,00%			0,50%	
EN 14562				0,50%	

Mixing table	Final concentration			
Final volume	0,5 %	1 %	2 %	3 %
1 Litre	5 ml	10 ml	20 ml	30 ml
2 Litres	10 ml	20 ml	40 ml	60 ml
4 Litres	20 ml	40 ml	80 ml	120 ml
8 Litres	40 ml	80 ml	160 ml	240 ml
10 Litres	50 ml	100 ml	200 ml	300 ml

B 1